



# ViewPoint Area Light 2.0

## Surface Mount Bracket

### INSTALLATION INSTRUCTIONS

#### CAUTION

PLEASE READ INSTRUCTIONS BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCE.

Electrical products can cause death or injury, or damage to property. If any doubt about the installation or use of this product, consult a qualified electrician.

#### WARNING

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance on this fixture, follow these general precautions.
- Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation

#### WARNING

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- Inspect each fixture for signs of damage before beginning installation; do NOT install any fixture that is damaged.
- Installation location must not hinder ventilation to the fixture unless product specifications indicate otherwise.
- All wiring connections should be capped with UL approved wire connectors.

#### CAUTION

- Avoid direct eye exposure to the light source while it is on.
- Account for small parts and destroy packing material, as these may be hazardous to children.
- Risk of burn. Disconnect power and allow fixture to cool before handling fixture.


**NOTICE:** Ground stud provided in proper location. Do not relocate.

**NOTICE:** Minimum 90° supply conductors.

**NOTICE:** Specifications and dimensions subject to change without notice.

**NOTICE:** Suitable for Damp or Dry location.

### General Wiring Diagram





# ViewPoint Area Light 2.0 Surface Mount Bracket

## INSTALLATION INSTRUCTIONS

### Installation Steps

**\*\*\*CAUTION: ENSURE TO APPLY A CONTINUOUS BEAD OF WEATHERPROOF CAULKING BETWEEN THE BRACKET AND THE WALL TO MAINTAIN WEATHERPROOF RATINGS**

1. Drill holes into the surface. (Figure 1)
2. Insert the expansion bolts into the surface. (Figure 2)
3. Attach fixture to Surface Mount Bracket with two Screws (provided). (Figure 3)
4. Wire fixture leads to supply wires and push the wires into Surface Mount Bracket. (Figure 4)
5. Securely mount the Surface Mount Bracket onto Expansion Bolts with nuts. (Figure 5)
6. If Conduit entry is desired, remove the Conduit cap as shown in Figure 3, feed the supply wires through the Conduit opening, wire the Fixture leads to the supply wires, push all wires into Surface Mount Bracket, and then follow the above mounting instructions




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5



# ViewPoint Area Light 2.0

## Surface Mount Bracket

INSTALLATION INSTRUCTIONS

### Dimension Drawing

